

Sir Safety System S.p.A. Single-member company Wholly-owned subsidiary of Sir Holding Srl Via dei Fornaciai, 9 - Santa Maria degli Angeli 06081 Assisi - Perugia - Italy Tel.+39 075.8043737 - Fax +39 075.8048686 VAT Nr. IT 03359340548 Viale Europa 74 20090 Cusago Milano Tel. +39 02.90394575 Fax +39 02.90394441

TECHNICAL SHEET

export@sirsafety.com www.sirsafety.com





Name: X-FLEX earplugs 10 pairs

Code: FC1113

3 FC11 EAR PROTECTION - EAR PLUGS

Description

Soft disposable earplugs in polyurethane foam, 23 mm long. Pack of 10 pairs.

Suitable for prolonged use.

1) They shall be rolled up on two fingers and then inserted into the ear canal. Expanding, they regain the original shape adapting to all forms of the earcanal.

2) Greatest degree of noise reduction currently available.

3) Preformed expanding polyurethane foam.

4) Cone-shaped, facilitating the correct insertion into the ear canal.

5) Slow-expanding foam to ensure a proper fit inside the ear.

6) Its smooth surface repels dirt, for maximum hygiene.

7) Hygiene guaranteed by the single packaging in polyethylene bags.

SNR 34 dB

Hertz frequency: H Attenuation = 33

Hertz frequency: M Attenuation = 31

Hertz frequency: L Attenuation = 30

Freq.(Hz)/Attenuation Med./Dev.standard/Value APV:63/27.6/ 4.9/22.7; Freq.(Hz)/Attenuation Med./Dev. standard/Value APV:125/31.6/4.9/26.7; Freq.(Hz)/AttenuationMed./Dev. standard/Value APV:250/34.3/5.1/29.2; Freq.(Hz)/Attenuation Med./Dev. standard/Value APV:500/35.8/5.0/30.8; Freq.(Hz)/Attenuation Med./Dev. standard/ValueAPV:1000/35.0/4.8/30.2; Freq.(Hz)/Attenuation Med./Dev. standard/ValueAPV:2000/35.4/4.0/31.4; Freq.(Hz)/Attenuation Med./Dev. standard/Value APV:4000/45.3/4.2/41.1; Freq.(Hz)/Attenuation Med./Dev. standard/Value APV:4000/45.3/4.2/41.1;

The product has been designed and manufactured to comply with Regulation (EU) 2016/425 and subsequent amendments.

Category	Colours	Available Sizes
III		In stock:
Quantity/Carton	EC Standards	Important Information
	EN 352-2	Suitable in noisy environments.
		Make sure the device is in good condition before use. Once you become aware of a damage, you should immediately replace it.
320		Keep in a cool dry place, far from heat sources. Keep the earplugs clean, so they do not attract dust and dirt before use, promoting proper hygiene in the ear canal.
		Disposable device: replace the earplugs after use.
Dexterity		Storage and cleaning