

Sir Safety System S.p.A. Single-member company Wholly-owned subsidiary of Sir Holding Srl Via dei Fornaciai, 9 - Santa Maria degli Angeli 06081 Assisi - Perugia - Italy Tel.+39 075.8043737 - Fax +39 075.8048686

Name: NEW OVERCAP BSF REX shoe

Code: MB2812Z9

VAT Nr. IT 03359340548

20090 Cusago Milano

Tel. +39 02.90394575

Fax +39 02.90394441

Viale Europa 74

9 MB28 FOOTWEAR - NEW OVERCAP SERIES

Description

Low shoe, with Action leather upper with nubuck leather inserts, closure with laces. Ankle band and tongue in tear-resistant oxfordfabric with sewn-in gussets for an excellent fit. Equipped with fiberglass toecap and composite midsole, PS type, with a constant thickness. The PU/TPU outsole, thanks to the special tread pattern, is self-cleaning and guarantees a highly draining effect in presence of liquids. The middle area, with a wide groove, is designed to enhance grip on ladders. SR slip resistant. The Fly Foam insole is made of polyurethane foam with anti-shock properties for prolonged use and it features a variable thickness: 4 mm in the front and9 mm in the heel area. The insole is laminated in polyester and has an antistatic treatment. The 3D-TEX polyester lining is specially designed to allow ventilation of the foot reducing the sweating effect.

Main features:

-Solid and modern design: suitable forterrains with ahigh degree of roughness and slippery surfaces

-Very wide shape, guarantees the comfortable housing of the feet -BASF polyurethane midsole guarantees a high anti-shock effect, lightness and resistance

- BASF TPU of the tread ensures longevity and great grip -The TPU toe cap protects the front leather from shocks

The product has been designed and manufactured to comply with Regulation (EU) 2016/425 and subsequent amendments.

Category	Colours	Available Sizes
II	BLACK	In stock: 38 - 48
Quantity/Carton	EC Standards	Important Information
5	EN ISO 20345	The footwear should be stored in a cool dry place, far from heat sources and direct light.Make sure footwear is in good condition, before use. If the shoes are damaged, replace them.Clean the footwear with a soft brush and water.
Dexterity		Storage and cleaning



export@sirsafety.com www.sirsafety.com



C B TTIFIB d Communication SETEMA DIGESTICAL CENTRALDIGESTICAL CENTRALDIGESTICAL UNI EN ISO 9001:2011